

**BLD10090**

Reducing adaptor 3/4" BSP(m) to 1/2" BSP(f)

**BLD10995**

Reducing adaptor 3/4" BSP(m) to 2" BSP(f)

**BLD10914**

Reducing adaptor 3/4" BSP(m) to 1/2" BSP(m)

**BLD10841**

Reducing adaptor 1" BSP(f) to 3/4" BSP(m)

**BLD10915**

Reducing adaptor 3/4" BSP(m) to 1" BSP(m)

**BLD10916**

Reducing adaptor 3/4" BSP(m) to 1 1/4" BSP(f)



BLD12308

Reducing adaptor 3/4" BSPP(m) to 1/4" BSPT(m)



BLD12307

Reducing adaptor 3/4" BSPP(m) to 3/8" BSPT(m)



BLD12214

Adaptor 3/4" BSPP(m) to 1/2" BSPT(m)



BLD12305

Adaptor 3/4" BSPP(m) to 3/4" BSPP(m)



BLD11000

Triangular adaptor flange with 3/4" BSP(m)
to DIN SPEC 42562



BLD10996

Flanged elbow adaptor to DIN SPEC 42567



BLD10930

DIN 42567 Flanged adaptor straight to BSP(m)



BLD11103

Plate adaptor with elbow to 3/4" BSP(m)



BLD11915

1" PNG Flange adaptor to 3/4" BSP(m)



BLD12213

3/4" BSPP(m) Adaptor to DN40 PN6 Flange

Unit 2 | Abbey Road Industrial Park | Commercial Way

Park Royal | London | NW10 7XF | T: +44 (0) 20 8965 9281

F: +44 (0) 20 8965 3239 | info@brownell.co.uk | www.brownell.co.uk



BROWNELL
L I M I T E D

Transformer Breather Spares



BLD7150

Rubber sealing ring for R, R1 & R2 Transformer breathers



BLD6935

Perforated Disc for R, R1 & R2 Transformer breathers



BLD11015

Extruded 'U' Gasket for V, W & X Transformer Breathers



BLD11157

Extruded 'U' Gasket for Y & Z Transformer Breathers